

Safe Artificial Intelligence: Theory, Understanding, & Application

In Association with IChemE

October 21-23, 2025

28th Process Safety International Symposium



Mary Kay O'Connor Process Safety Center



Richard MacNguyen

- Extensive experience leading FSS and QRA projects in oil, gas, LNG, and specialty chemical industries worldwide
- Instructor for QRA and Consequence Modeling courses using DNV Phast & Safeti developed for operating companies
- AcuTech since 2022; 15 yrs process safety & industry experience



In Association with IChemE



QRAs Are Widely Applied for Normal Operating (Static) Risks

- Quantify risks to
 - People
 - onsite, offsite, occupied buildings
 - Environment
 - Business
- **Do Not Generally Address**
 - Startup (S/U) and shutdown (S/D)
 - SIMOPS
 - Turnarounds
 - Maintenance
 - Construction







Accidents Occur 5x More Often During Abnormal Operations¹



Increased risk of process upsets, due to temporary modifications to equipment, process conditions, and procedures.



Increased risk of misalignment or human error as part of shutdown, isolation, de-inventory, maintenance, and startup activities due to the complexity of work scope.



Increased risks from external factors

(e.g., adjacent work activities, vehicle traffic, lifting devices).



Increased intensity and stress on workers.



Increased numbers of workers present in and around hazardous process areas.




Increased use of temporary occupied structures.



Mary Kay O'Connor

Process Safety Center



Normal Operations (Static) QRAs Can Evaluate Abnormal (Dynamic) Operations with a Straightforward Approach

Topics:

- A method to develop a Dynamic QRA using DNV Safeti
- An example QRA assessing the risk profile of a Turnaround (T/A) with complex integrated process operations, including Startup (S/U) and Shutdown (S/D)



Mary Kay O'Connor

Process Safety Center

In Association with IChemE

Defining the Scope



Dependent on the operation being planned (T/A, SIMOPS, Expansion)



S/U, S/D, and maintenance/construction activities are staged over a period of time



Define the distinct operating/risk time periods for the operation



In Association with IChemE



Consider the Risks

of S/D
operations increases risk of
upsets.

Completion of S/D and de-inventory - reduces risk of upsets.

of S/U
operations increased risk of
upsets.

Return to normal operation, S/U complete – Risk returns to baseline level.




In Association with IChemE



Case Study-A Multi-Unit T/A

- S/D and S/U operations for multiple units must be considered
- Time periods do not refer to specific dates, but rather milestones
 - e.g., Units 3-63 & 6-73 S/D complete



Color coding		Description									
Normal ops		Unit operates normally									
Online starts	0	Start-up operations start on unit									
Online		Start-up operation are being carrierd on the unit									
Shutdown		Shut-down operations are being carried on the unit									
Offline starts	Χ	Unit stops to operate									
Offline		Unit is not operating									




Mary Kay O'Connor

In Association with IChemE

Case Study-A Multi-Unit T/A

- A T/A will result in hazards being removed as units S/D, then returning as units start up
- Units that are S/D still present areas of obstruction for VCE risks
- Units in operation during this period still present hazards and risks may be increased during this period
- The dynamic risk profile is dependent on the specific operation plan






Mary Kay O'Connor

Process Safety Center

In Association with IChemE

Case Study-A Multi-Unit T/A

- A T/A will result in hazards being removed as units S/D, then returning as units start up
- Units that are S/D still present areas of obstruction for VCE risks
- Units in operation during this period still present hazards and risks may be increased during this period
- The dynamic risk profile is dependent on the specific operation plan






Texas A&M Engineering Experiment Station

In Association with IChemE

Objectives for Multi-Unit T/A QRA

- Identify potential mobilization areas for workers
- Define when essential workers must be onsite
- Define the proposed temporary structures.
- Consider special requirements for light wood trailers and nonessential personnel under API RP 753






Mary Kay O'Connor

- The Safeti risk model evaluates the individual and aggregate risks
- Inputs Include:
 - LOCs, Locations, and Frequencies
 - Immediate Ignition Probabilities

- Delayed Ignition Zones
- Obstructed Regions
- Weather/Wind Conditions & Probabilities
- Populations
- Terrain





In Association with IChemE



Mary Kay O'Connor Process Safety Center


Texas A&M Engineering Experiment Station













- Run rows and the combinations matrix upgrade a static QRA to a dynamic QRA
- In our T/A example
 - Each process unit is separated into unique run rows to capture the range of outcomes for each time period
 - Run rows were expanded from 28 to 78

	Day	Hazard	Confined	TP1	TP2	TP3	TP4	TP5	TP6	TP7	TP8	ТРЭ	TP10	TP11	TP12	TP13	TP14	TP15	TP16	TP17	TP18	TP19
Unit	Night	Type	Unconfined		-	- 1	_	_				_										
Unit 13	Day	FLAM	Open	0	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	0.4
Unit 13		FLAM	Open	1	6	6	6	6	6	6	6	6	6	6	6	6	6	6	6	6	6	0.6
Unit 13	+	FLAM	Open	1	6	6	6	6	6	6	6	6	6	6	6	6	6	6	6	6	6	0.6
Unit 13	Day	FLAM	Open	0	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	0.4
Unit 7	Day	FLAM	Open	0	4	4	4	4	0	0	0	0	0	0	0	4	4	4	4	4	4	0.4
Unit 7	Night	FLAM	Open	1	6	6	6	6	0	0	0	0	0	0	0	6	6	6	6	6	6	0.6
Unit 7	Day	TOXIC and FLAM	Open	0	4	4	4	4	0	0	0	0	0	0	0	4	4	4	4	4	4	0.4
Unit 7	Night	TOXIC and FLAM	Open	1	6	6	6	6	0	0	0	0	0	0	0	6	6	6	6	6	6	0.6
Unit 3	Day	FLAM	Open	0	4	4	4	4	0	0	0	0	0	0	0	0	0	0	0	0	6	0.6
Unit 3	Night	FLAM	Open	1	6	6	6	6	0	0	0	0	0	0	0	0	0	0	0	0	6	0.6
Unit 6	Day	FLAM	Open	0	4	4	4	4	4	4	4	4	0	0	0	0	0	0	0	0	4	0.4
Unit 6	Day	FLAM	Open	0	4	4	4	4	4	4	4	4	0	0	0	0	0	0	0	0	4	0.4
Unit 2	Day	FLAM	Open	0	4	4	4	4	4	4	4	4	4	0	0	0	0	0	0	4	4	0.4
Unit 2	Day	FLAM	Confined	0	4	4	4	4	4	4	4	4	4	0	0	0	0	0	0	4	4	0.4
Unit 6	Day	FLAM	Open	0	4	4	4	4	4	4	4	4	4	0	0	0	0	0	0	4	4	0.4
Unit 6	Night	FLAM	Open	1	6	6	6	6	6	6	6	6	0	0	0	0	0	0	0	0	6	0.6
Unit 6	Night	FLAM	Open	1	6	6	6	6	6	6	6	6	0	0	0	0	0	0	0	0	6	0.6
Unit 2	Night	FLAM	Open	1	6	6	6	6	6	6	6	6	6	0	0	0	0	0	0	6	6	0.6
Unit 2	Night	FLAM	Confined	1	6	6	6	6	6	6	6	6	6	0	0	0	0	0	0	6	6	0.6
Unit 6	Night	FLAM	Open	1	6	6	6	6	6	6	6	6	6	0	0	0	0	0	0	6	6	0.6
Unit 4	Day	FLAM & TOX	Open	0	4	4	4	4	4	4	0	0	0	0	0	0	4	4	4	4	4	0.4
Unit 4	Day	FLAM & TOX	Open	0	4	4	0	0	0	0	0	0	0	0	0	0	4	4	4	4	4	0.4
Unit 4	- '	FLAM & TOX	Open	1	6	6	6	6	6	6	0	0	0	0	0	0	6	6	6	6	6	0.6
Unit 4			Open	1	6	6	0	0	0	0	0	0	0	0	0	0	6	6	6	6	6	0.6




In Association with IChemE



- For each time period, combination factors are adjusted to account for the increase or decrease in risk contribution
- Risk may increase across multiple units during S/D of a single unit
- Consider the magnitude and scope of the risk factors to be applied for the operation

Example Sum of Combination Factors Through T/A







Considerations under API 753 Second Edition, 2024


- Within 330' of the hazard source (e.g., congested volume or source for a fire/flammable release), nonessential personnel shall not be assigned.
- The risk-based approach **shall** not be used to site <u>LWTs or nonessential personnel</u> in a portable building in <u>Zone 1</u>.
- The following requirements **shall** be used for siting portable buildings <u>regardless</u> of the method used (Zoning Method A or B).


Zone Number	Light Wood Trailers	Light Wood Trailers Portable Buildings Other Than Light Wood Trailers								
Zone 1	Not Allowed	Siting Evaluation Required	House Only Essential Personnel							
Zone 2	Siting Evaluation Required	Siting Evaluation Required	See <u>Section 6</u> for Restrictions							
Zone 3	No Restrictions	No Restrictions	See <u>Section 6</u> for Restrictions							





Enclosed Vapor Accumulation (EVA) model





Considering Risk Criteria

- Should Transitory Risks be More Acceptable than Baseline Risks?
- Individual risk and societal risk are generally presented as risk per annum





- API RP 753 2nd Ed. States
 - When evaluating individual risk, "No credit shall be taken for cases where the building will not be used or located at the site for less than a year"





Considering Risk Criteria

- Should Transitory Risks be More Acceptable than Baseline Risks?
- Individual risk and societal risk are generally presented as risk per annum







- API RP 753 2nd Ed. States
 - For societal risk calculations, operators may account for the limited duration of the nonroutine operation, which contributes only a portion to the site's annualized aggregate risk







- Location specific individual risk (LSIR)
 - Expressed as a predicted likelihood of impacts by a fatal hazard on an annualized basis
 - Risk to a person present at a location for a year
- The risk measure is also expressing the instantaneous risk exposure to a person in a location at a moment in time
- LSIR for a worker is not affected by the time they are present
- Permanent and temporary workers are both exposed to the same risk levels at any moment in the same location














- Temporary contract workers may work at multiple sites throughout the year
- If operators relaxed risk criteria, the result would be a significant increase in the worker's risk exposure
- A prudent decision is not to relax risk criteria during non-routine operations





In Association with IChemE




Results are Developed for Each Time Period Combination

Areas	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
A	2.9E-5	2.9E-5	2.9E-5	2.8E-5	2.8E-5	6.5E-6	4.3E-6	3.4E-6	3.4E-6	1.0E-6	1.0E-6	1.0E-6	1.0E-6	2.6E-5	2.6E-5	2.9E-5								
В	6.6E-5	6.6E-5	6.6E-5	6.6E-5	6.6E-5	2.4E-5	4.3E-6	2.6E-6	2.6E-6	6.1E-7	6.1E-7	9.1E-7	9.1E-7	4.7E-5	4.7E-5	6.6E-5								
С	1.4E-3	1.4E-3	1.4E-3	7.7E-4	7.7E-4	7.7E-4	9.1E-5	9.1E-5	8.9E-5	7.1E-5	7.0E-5	7.0E-5	7.0E-5	7.3E-4	7.3E-4	1.4E-3								
D	1.1E-4	1.1E-4	1.1E-4	8.1E-5	8.1E-5	7.0E-6	7.0E-6	6.6E-6	6.6E-6	4.6E-8	1.9E-8	1.9E-8	7.4E-5	1.0E-4	1.0E-4	1.0E-4	1.0E-4	1.0E-4	1.1E-4	1.1E-4	1.1E-4	1.1E-4	1.1E-4	1.1E-4
E	2.1E-4	2.1E-4	2.1E-4	1.9E-4	1.9E-4	1.1E-5	1.1E-5	1.1E-5	1.0E-5	1.3E-7	1.3E-8	1.3E-8	1.8E-4	2.0E-4	2.0E-4	2.0E-4	2.0E-4	2.0E-4	2.1E-4	2.1E-4	2.1E-4	2.1E-4	2.1E-4	2.1E-4
F	1.3E-4	1.3E-4	1.3E-4	1.3E-4	1.3E-4	6.0E-7	6.0E-7	4.6E-7	4.6E-7	4.7E-9	4.7E-9	4.7E-9	1.3E-4											
I	2.8E-4	2.8E-4	2.8E-4	2.8E-4	2.8E-4	6.6E-5	6.6E-5	6.6E-5	6.6E-5	5.3E-5	5.3E-5	2.0E-4	2.0E-4	2.8E-4										
J	3.4E-4	3.4E-4	3.4E-4	3.4E-4	3.4E-4	4.8E-5	4.8E-5	4.7E-5	4.7E-5	3.5E-5	3.5E-5	2.1E-4	2.1E-4	3.4E-4										
K	4.9E-4	4.9E-4	4.9E-4	4.1E-4	2.6E-4	2.5E-4	6.3E-6	5.8E-6	5.8E-6	2.1E-6	2.1E-6	2.1E-6	2.1E-6	9.4E-5	9.4E-5	3.4E-4	4.9E-4							
L	7.2E-4	7.2E-4	7.2E-4	1.7E-4	4.4E-5	3.9E-5	5.0E-6	4.4E-6	4.4E-6	2.0E-6	2.0E-6	2.0E-6	2.3E-6	5.6E-4	5.6E-4	5.9E-4	7.2E-4							
M	3.6E-4	3.6E-4	3.6E-4	3.6E-4	3.6E-4	3.6E-4	3.5E-4	3.5E-4	2.9E-4	2.3E-4	2.3E-4	2.3E-4	2.3E-4	2.3E-4	2.3E-4	2.5E-4	3.0E-4	3.0E-4	3.6E-4	3.6E-4	3.6E-4	3.6E-4	3.6E-4	3.6E-4
N	3.5E-4	8.1E-5	2.9E-5	2.9E-5	2.9E-5	2.9E-5	2.9E-5	2.9E-5	3.0E-5	3.0E-4	3.0E-4	3.5E-4	3.5E-4	3.5E-4	3.5E-4	3.5E-4	3.5E-4							
0	4.7E-4	4.7E-4	4.7E-4	4.7E-4	4.7E-4	1.5E-4	1.5E-4	1.5E-4	1.0E-4	2.2E-6	2.2E-6	2.2E-6	1.8E-5	1.9E-5	1.9E-5	1.9E-5	6.3E-5	6.3E-5	5.4E-4	5.4E-4	5.4E-4	5.4E-4	5.4E-4	5.4E-4










In Association with IChemE





https://www.youtube.com/watch?v=9y-0pazEvaE




In Association with IChemE



Mary Kay O'Connor Process Safety Center

Texas A&M Engineering Experiment Station





In Association with IChemE



Reducing Risks in Abnormal Operations & T/A



Co-locate equipment for S/D in adjacent areas,
or time process unit
shutdowns and
downtimes by area.

Equipment that continues to present risk in the area will limit the ability to locate personnel during T/A, even after units are shutdown.



Reconsider using tanks near process units during T/A.

Consider shifting storage operations to eliminate or limit the use of tanks near work areas to reduce the risk



Construct temporary structures, prior to the T/A to minimize risk from S/D operations

Avoid workers assembling/siting buildings during periods of increased risk.



Develop a system to manage and control occupancy once buildings are sited

Access control and signage, as well as periodic reviews.



Evaluate effects on adjacent or interconnected units during non-routine operations.

Operations may be impacted by changes in feed/product routing, reduced staffing levels, capacity changes, or other risk factors.



In Association with IChemE



Questions?

www.acutech-consulting.com

